

BEE35

Manual



SpeedyBee APP




Installation guide



Facebook QR Code

■ CNC head part installation





■ Antenna Installation Sequence

insert the O-ring into the antenna to secure it on the TPU antenna base.



◆ FC Mounting Hole | Motor Mounting Hole





Recommended cable length for 25.5 AIO: 52mm
Recommended cable length for 20mm MINI: 62mm




*(Note: Assembly diagram, motor not included in the frame)


1:1 Scale



Multi-function Antenna Mount



◆ CNC cooling part installation



● Suggesting place for main power cable



It is recommended to keep the power cable of ESC to be about 100mm.
Please refer to your own battery for actual length.

◆ CNC cooling part installation




M2 (6mm) button head hex socket screw

O3 Air Unit or RunCam Link installation
O3 Air Unit或RunCam Link


● Bottom screw installation




Installation Illustration



T-antenna installation



◆ Detachable anti-vibration camera base mount



Note: This accessory needs to be purchased separately